



New Zealand 0800 998 000



Australia 1800 351 359

---

## UD5 DIVIDER INSTALLATION INSTRUCTIONS

POSITION DIVIDER EVENLY BETWEEN URINALS AT A HEIGHT OF 1300mm AT THE TOP SCREW MAKING SURE YOU HAVE THE WIDER SECTION OF DIVIDER AT THE TOP

SCREW SMALL BRACKET INTO STUD OR NOG AT 910mm

IF NO STUD OR NOG AT SCREW HOLES USE PLASTIC RAWL PLUGS TO MAKE SURE SCREWS BITE AND HOLD

