



**TEMPLATE FOR BORONIA HPKV ST 2244**

- INSTALLATION GUIDELINES:**
1. Cut out the Screw according to the Dotted Pencil line
  2. Use a sharp pencil and mark the position of the Screw according to the Template.

**BORONIA HPKV ST 2244**

WATERLESS WALL URINAL

**For enquiries, please forward them to the following address and contact number(s):-**

**SANITON CERAMIC PTE LTD**  
 54 Woodlands Industrial Park E  
 Singapore 757826  
 Email : sales@saniton.com <http://www.saniton.com>  
 TEL: +65 - 6753 3627 / 6758 5770, FAX: +65 - 6755 0782